

FBD-NT Press Brake Installation Guide

Summary.....	2
Environmental conditions	2
Power supply	2
Machine installation	3
Location	4
Carrying	5
Using a crane	5
Using rollers	6
Foundation	7
Cleaning.....	7
Supplying hydraulic oil	8
Removing shipping brackets.....	9
Supplying electric power	10
Changing power supply parts.....	10
Connecting power cable.....	13
Checking wiring connections.....	15
Re-origin	16
Connecting air compressor.....	16
Leveling.....	17
Paralleling upper and lower beams	18
Checking movement of each axis.....	19
Installing stopper fingers	20
Making final checks.....	20

SUMMARY

Environmental conditions

- The higher the humidity in the place where the machine is installed, the lower the insulation performance of its electric parts becomes. This results in the premature degradation of the electric parts. Do not install the machine in such a humid place.
- Where the ambient temperature is not higher than 5°C (41°F), keep the machine and hydraulic unit energized during the day's work.
- Install the machine in a place where it is not subjected to dust, dirt, and organic or corrosive gases.
- Keep the machine at least 10 m (33 ft) away from a welder or any other equipment that may produce electric noise and magnetic fields.

Power supply

Power requirement: 200/230/400/460 V, AC, 3 phases, 50/60 Hz


Power cable: Composed of four conductors (including grounding conductor) and thick enough to carry required power

Model	Power voltage	Full load current				Power cable and ground conductor (AWG)		
		200 V	230 V	400 V	460 V	200/230V	400 V	460 V
3512	200/230/400 /460 V	37 A	32.2 A	18.5 A	15.9 A	8 mm ² (8)	5.5 mm ² (10)	5.5 mm ² (10)
5012		44 A	38.3 A	22 A	18.9 A	14 mm ² (6)	8 mm ² (8)	8 mm ² (8)
5020		44 A	38.3 A	22 A	18.9 A	14 mm ² (6)	8 mm ² (8)	8 mm ² (8)
8020		44 A	38.3 A	22 A	18.9 A	14 mm ² (6)	8 mm ² (8)	8 mm ² (8)
8025		44 A	38.3 A	22 A	18.9 A	14 mm ² (6)	8 mm ² (8)	8 mm ² (8)
1025		59 A	51.3 A	29.5 A	25.4 A	22 mm ² (4)	14 mm ² (6)	14 mm ² (6)
1030		59 A	51.3 A	29.5 A	25.4 A	22 mm ² (4)	14 mm ² (6)	14 mm ² (6)
1253		59 A	51.3 A	29.5 A	25.4 A	22 mm ² (4)	14 mm ² (6)	14 mm ² (6)

NOTICE

- Supply the machine from a power source independent of a welder or any other equipment that may produce line voltage variations.

Machine installation




LOCATION

The place where the machine is to be installed must have an ample floor space. Refer to the machine dimensions given in the table below. Also take the following points into account:

- There must be no pillars and other obstacles in the area where the tools are mounted and removed. (At least 835 mm (32.9 in.) long tools must be able to be horizontally mounted and removed.)
- The ceiling must be at least 1000 mm (40 in.) from the top of the machine.
- There must be an additional space to place a tool storage case and an air compressor.
- There must be a work space where the worksheets can be easily moved in and out and where maintenance and part quality check can be smoothly performed. Especially, a work space of 1000 mm (40 in.) or more must be available at the rear of the machine, and an enough space must be available for the door of the electrical enclosure to be opened.

NOTICE

- Do not install the machine in a place where it is exposed to dust from such operations as sandblasting and to direct sunlight, rain or wind.



Unit: mm (in.)

Model	A	B	C	D
3512	2040 (80.38)	1990 (78.41)	680 (26.79)	1890 (74.47)
5012	2040 (80.38)	1990 (78.41)	680 (26.79)	1890 (74.47)
5020	2860 (112.69)	1985 (78.21)	680 (26.79)	2570 (101.26)
8020	2880 (113.48)	2060 (81.17)	680 (26.79)	2610 (102.84)
8025	3380 (133.18)	2060 (81.17)	680 (26.79)	3110 (122.54)
1025	3380 (133.18)	2060 (81.17)	680 (26.79)	3110 (122.54)
1030	3875 (152.68)	2060 (81.17)	680 (26.79)	3610 (142.24)
1253	3905 (153.86)	2075 (81.76)	680 (26.79)	3630 (143.03)

CARRYING




WARNING

- Carrying the machine is very dangerous. Have a qualified contractor perform the carrying work.

Using a crane


When lifting the machine, apply the wire rope sling to the lifting ribs at the top of the frame, slowly lift and carry the machine to the location, and slowly lower the machine at the location. The wire rope sling must be strong enough to carry the weight of the machine. (For the weight of the machine, see the serial number plate attached to the machine.)




Using rollers

First jack up the front bottom of the machine under the left and right main cylinders, and place rollers under the front feet of the machine. Then slowly jack up the rear bottom of the machine, and place rollers under the rear feet of the machine. Pay attention to the balance of the machine when jacking up. Fix the rollers to the machine through the anchor bolt holes. Slowly roll the machine to its location.

SIDE VIEW



TOP VIEW




The shaft marked by an asterisk (*) is used to connect the two rollers at the right side of the machine. (Three rollers are shown in the drawing.)

NOTICE

- Be sure to first jack up the front bottom of the machine under the main cylinders.
- The machine has a center of gravity at its front. If the rear bottom of the machine is jacked up without paying attention to its balance, the machine may tip over, resulting in a very dangerous situation.

FOUNDATION

To maintain bending accuracy, install the machine on a flat concrete floor that is strong enough to carry the weight of the machine and is not likely to subside.



Unit: mm (in.)

Unit: mm (in.)

Model	A	B
3512	2570 (101.26)	1990 (78.41)
5012	2570 (101.26)	1990 (78.41)
5020	3250 (128.05)	1985 (78.21)
8020	3290 (129.63)	2060 (81.17)
8025	3790 (149.33)	2060 (81.17)
1025	3790 (149.33)	2060 (81.17)
1030	4290 (169.03)	2060 (81.17)
1253	4310 (169.81)	2075 (81.76)

CLEANING

After the machine is installed on the foundation, clean it. Particularly, remove all rust-preventive grease from the punch holders, the die holders, and the top surface of the lower beam, using cleaning oil.

NOTICE

- Do not use a solvent or scraper that removes the paint of the machine.

SUPPLYING HYDRAULIC OIL


The hydraulic unit is located at the rear of the machine. Remove the cover of the hydraulic unit, and pour the recommended hydraulic oil into the hydraulic unit tank to slightly above the center mark of the oil gauge when the lower beam is at the lower limit.

Model	Tank capacity Liters (US gal)
3512, 5012, 5020, 8020, 8025	70 (18.4)
1025, 1030, 1253	90 (23.7)

Recommended oil

For use at normal temperature: Esso Teresso 46 and Shell Tellus Oil 46
(ISO VG56 Viscosity Index 113)


For use at lower temperature: Esso Spinesso 22 and Shell Tellus Oil
C22




REMOVING SHIPPING BRACKETS

After the machine has been installed in place, remove the shipping brackets securing the backgauge. The shipping brackets are each fixed with two bolts. (Replace the bolts in their holes.)


SIDE VIEW



TOP VIEW



SUPPLYING ELECTRIC POWER

 WARNING	<ul style="list-style-type: none">● Have a qualified electrician perform all electric work to prevent accidents and damage.● Before making the electrical connections, be sure to turn off the shop circuit breaker.● Be sure to connect the grounding conductor for safety.● Use the shop circuit breaker and grounding conductor exclusively for the machine, and separate from those of other equipment such as welders, drills, sanders, and grinders.
--	---

NOTE

- The machine needs a 200/230/400/460 V and 3-phase power supply.
- Use the power cable and grounding conductor that suit the power to be handled.

Changing power supply parts

If the power supply voltage is different from the transformer and motor connection voltage shown on the label affixed to the electrical enclosure of the machine, the power supply parts must be changed. For the wiring of each part, refer to the electric circuit diagram in the appendix.

Change the power supply parts as described below.

- 1 Turn off the shop circuit breaker.
- 2 Open the door of the electrical enclosure at the left side of the machine.
- 3 Turn off the circuit breaker QF1.
- 4 Turn off the motor circuit breaker QM1.
- 5 Change the following parts:
 - Circuit breaker QF1
 - Motor circuit breaker QM1
 - Thermal relay FR1
 - Fuses F1 and F2
 - Varistors RV1 to RV3

6 Change the main motor power cables.

- When changing from 200/230 V to 400/460 V


Disconnect the three cables between the thermal relay and the lower terminal block XT2, and install two jumper connectors at the lower terminal block XT2.

- When changing from 400/460 V to 200/230 V

Remove the two jumper connectors from the lower terminal block XT2, and connect the three cables between the thermal relay and the lower terminal block XT2.


200/230 V connections

No.	From	Marker tube	Length	Marker tube	To
1	FR1-2	U	350	Y	XT2-Y (upper)
2	FR1-4	V	350	Z	XT2-Z (upper)
3	FR1-6	W	350	X	XT2-X (upper)




400/460 V connections

No.	From	Marker tube	Length	Marker tube	To
1	XT2-X (upper)	X	150	Y	XT2-Y (upper)
2	XT2-Y (upper)	Y	150	Z	XT2-Z (upper)



7 Change the primary taps of the transformer TC1 as shown below.



8 Set the thermal relay FR1 at the values shown in the table below.

Model		3512	5012	5020	8020	8025	1025	1030	1253
Hydraulic pump motor output: kW (HP)		5.5 (7.5)	7.5 (10)	7.5 (10)	7.5 (10)	7.5 (10)	11 (15)	11 (15)	11 (15)
Thermal relay setting: A	200 V	22.4	29.9	29.9	29.9	29.9	40.3	40.3	40.3
	230 V	19.5	26	26	26	26	35	35	35
	400 V	13.2	17.8	17.8	17.8	17.8	20.7	20.7	20.7
	460 V	11.5	15.5	15.5	15.5	15.5	18	18	18

Connecting power cable

Connect the power cable to the machine as described below.

- 1 Turn off the shop circuit breaker.
- 2 Open the door of the electrical enclosure at the left side of the machine.
- 3 Turn off the machine circuit breaker.
- 4 Run the power cable from the shop circuit breaker through the hole into the electrical enclosure.
- 5 Connect the power cable to the power input terminals L1, L2, and L3 in the electrical enclosure.
- 6 Connect the grounding conductor to the ground terminal PE.

NOTE

- Use a grounding conductor of at least the same size as that of the power cable conductors.

- 7 After the electric wiring connections are completed, check the voltage with a tester.

When the power supply parts are changed, check the voltage with a tester as described below.

- (1) Turn off the shop circuit breaker.
- (2) Change the machine to the following conditions:
 - Turn off the circuit breaker QF1.
 - Turn off the motor circuit breaker QM1.
 - Remove the fuse FU3.
 - Turn off the circuit protectors QF3 to QF5.
- (3) Turn on the shop circuit breaker.
- (4) Check the input voltage between the terminals L1 and L2, L2 and L3, and L1 and L3 at the lower terminal block.
- (5) Check the input voltage between the terminals L1 and L2, L2 and L3, and L1 and L3 at the primary side (upper terminal block) of the circuit breaker QF1.
- (6) Turn on the circuit breaker QF1.
- (7) Check the input voltage between the terminals L11 and L21, L21 and L31, and L11 and L31 at the secondary side (lower terminal block) of the circuit breaker QF1.
- (8) Check the output voltage at the secondary side of the transformer TC1.
- (9) Check the input voltage between the terminals L11 and L21, L21 and L31, and L11 and L31 at the primary side (upper terminal block) of the motor circuit breaker QM1.
- (10) Turn on the motor circuit breaker QM1.

- (11) Check the input voltage between the terminals L12 and L22, L22 and L32, and L12 and L32 at the secondary side (lower terminal block) of the motor circuit breaker QM1.
- (12) If the above voltage checks find no problems, turn off the circuit breaker QF1.
- (13) Return the machine to the following conditions:
 - Replace the fuse FU3.
 - Turn on the circuit protectors QF3 to QF5.

8 Replace the cover of the electrical enclosure.

Checking wiring connections



CAUTION


- When turning on the power of the machine for the first time as described below, keep one hand at the **POWER ON/OFF** switch so that you can turn off the power of the machine as soon as possible.

Check the wiring connections as described below.

- 1 Turn on the shop circuit breaker.
- 2 Turn on the machine circuit breaker, and check that the **POWER** light comes on.
- 3 Turn the **POWER ON/OFF** switch to **ON**. When the initial **NC** display is shown and a beep is heard, the hydraulic pump motor can be started.
- 4 Press the **HYDRAULIC ON** button. The hydraulic pump motor starts, and the **HYDRAULIC ON** button lights.
- 5 Check the rotational direction of the hydraulic pump motor. The correct rotational direction is indicated by the arrow in the figure below. If the hydraulic pump motor runs in the reverse direction, immediately press the **HYDRAULIC OFF** button, turn off the machine circuit breaker, and interchange two of the three conductors connected to the terminals **L1**, **L2**, and **L3**.

NOTICE

- The hydraulic pump will fail if its motor is left to run in the reverse direction for a long period of time. When the hydraulic pump motor is found running in the reverse direction after the **HYDRAULIC ON** button is pressed, immediately press the **HYDRAULIC OFF** button.



RE-ORIGIN

After the power of the machine is turned on, be sure to zero-return the machine. Unless the zero-return is performed, each axis cannot move.

Zero-return the machine as described below.

- 1 Touch the SETUP button shown on the screen.
- 2 Press and hold the UP foot pedal. Each axis zero-returns.

CONNECTING AIR COMPRESSOR

When the backgauge is equipped with optional flip-up stopper fingers, compressed air must be supplied to the machine.


The air combination unit is located at the rear of the machine (inside the right side frame). Fully connect the pipe or hose (inner diameter of 3/8 in.) from the air compressor to the air inlet (joint of 3/8 in.).

The required air pressure for the machine is 0.5 MPa (5 kg/cm², 70.97 psi). The air compressor used should have a output of 0.75 kW (1 HP) or more.

NOTICE

- If a pipe or hose with an inner diameter of less than 3/8 in. is used, the air flow will be limited and the air pressure will be reduced.
- Install the air compressor near the machine. If the air compressor is away from the machine, the air pressure will be reduced.


Air combination unit



LEVELING

Level the machine as described below.

- 1 Turn the MODE SELECT switch to OFF with the HYDRAULIC ON button lighted and the hydraulic pump motor running.
- 2 Place a spirit level on the lower beam.
- 3 Attach square spirit levels to the working surface at the rear of the left and right side plates of the machine.
If square spirit levels are not available, place spirit levels at the left and right edges of the top surface of the lower beam.
- 4 Turn the leveling bolts to level the machine to 0.03 mm/1m (0.001 in./1ft.) or less in the left-to-right and front-to-back directions.



PARALLELING UPPER AND LOWER BEAMS


Check that the upper and lower beams are parallel at the left edge D1 and right edge D2 as shown below. If not, parallel them as described below.

- 1 Remove the punch holders at the left and right edges.
- 2 Turn the MODE SELECT switch to UPPER LOCK.
- 3 Raise the lower beam to 140 mm (5.52 in.), and measure the dimensions D1 and D2.
- 4 If the dimension D2 is greater than the dimension D1 (0.00), add the difference to the grid shift of the dimension D1. If the dimension D2 is smaller than the dimension D1, add the difference to the grid shift of the dimension D2.

NOTE


- The grid shift is adjusted by changing the value of a system parameter. For the method of displaying the system parameter, refer to the adjustment specification.

- 5 Turn off the power and then back on, and repeat steps 1 to 3.
- 6 Repeat steps 1 to 5 so that the difference between the dimensions D1 and D2 becomes 0.01 mm (0.0004 in.).
- 7 When the paralleling of the upper and lower beams is completed, check that the machine is level with the lower beam positioned 140 mm (5.52 in.). If not, level the machine again.



CHECKING MOVEMENT OF EACH AXIS

Be sure to check the movement of each axis. Manually move each axis, and check that each axis moves free of trouble.




NOTE

● If the lower beam tilts or stops midway, lower the lower beam as described below.


- 1 Turn the POWER ON/OFF switch to ON.
- 2 Press and hold the RAM DOWN button until the lower beam reaches the bottom dead center.
- 3 Turn the POWER ON/OFF switch to OFF and then back to ON.
- 4 Re-origin the machine.

INSTALLING STOPPER FINGERS


	WARNING	● Never reach through the space between the punches and dies to change the stopper fingers. Turn the MODE SELECT switch to OFF during the change.
---	----------------	---

The machine is shipped with the stopper fingers removed. Install them as described below.

- 1 Move the stoppers to the position where they can be reached through the gap.
- 2 Turn the MODE SELECT switch to OFF.
- 3 Install a stopper finger of the same number as that marked on the stopper as shown below.



STOPPER FINGER



STOPPER

MAKING FINAL CHECKS

- Interference of lower beam with cover
Move up the lower beam over a full stroke, and press the EMERGENCY STOP button. Press the RAM DOWN button intermittently to bring down the lower beam. When the lower beam does not interfere with the cover, move up and down the lower beam continuously, and check it for any interference with the cover.
- Oil leakage and air removal
Check for any oil leak. After tools are mounted, move up the lower beam to apply pressure to the tools for a few seconds. This forces air out of the hydraulic unit.